

1 Preparing the subfloor

Puzzle mats should preferably be installed on a flat, stable, and load-bearing surface. Ensure that the surface is dry, clean, and free of dust before starting the installation.

2 Laying the Mats

- Measure the surface carefully.
- Start from a straight edge.
- Do not place the mats too tightly against fixed objects, allowing the material to expand and contract due to temperature variations.
- Thanks to the integrated puzzle connections, the mats can be easily joined together.
- For a stable and neat finish, ensure that the joints fit together properly and that the mats are evenly distributed across the surface.



3 Cutting Puzzle Mats to Size

Use a straightedge or ruler to mark the cutting line accurately. Moisten the blade of the knife for a clean cut. Straight cuts can be made using a hand saw, jigsaw, or utility knife. For shaped cuts and patterns, a jigsaw is recommended.

Important: Ensure the Correct Side Faces Up

When laying the puzzle mats, make sure they are positioned with the correct side facing up. Due to the manufacturing process, in which the mats are cut from a block, each mat has one smoother side and one rougher side. For optimal performance and finish, position the mats with the smooth side facing up and the rougher side facing down.

4 Installation > Puzzle Connections

Aslon® Puzzle Mats feature an integrated puzzle connection system, allowing the mats to interlock easily and create a stable floor without connecting pins. No glue or tape is required for installation. The interlocking connections ensure a secure and stable fit without the need for additional fixing materials. During installation, regularly check that all puzzle connections are fully engaged.

