

Aslon® installation instructions for rubber FITNESS tiles

SURFACE:

Make sure you have a flat subsurface. If the subsurface does not consist of concrete, please contact Aslon Rubber

PRODUCT FEATURE:

Rubber granulate products may have a width tolerance/variation of up to 2% and a thickness tolerance of up to 5%. These rubber granulate products are manufactured from recycled rubber containing Carbon black, which can serve as an external black coloring agent.

TOOLS:

Use appropriate tools such as a straight edge or ruler, a hand saw with coarse teeth, a low-speed jigsaw with coarse teeth, a utility knife, or a similar blade. Never use an angle grinder, miter saw, or table saw.

INSTALLATION PROCEDURE:

- Ensure accurate measurements (consider expansion and contraction of tiles due to weather conditions when products are used outside).
- Place the tiles on a concrete subfloor.
- Lay the tiles in a staggered pattern (half-bond), which ensures the best and most stable placement.
- Dampen the cutting edge of the knife.
- If needed, use a jigsaw for cutting patterns.
- When processing artificial grass tiles please always note the arrows on the bottom of the tiles

GLUEING: (For outdoor tiles only)

- The processing temperature should be at least 8°C.
- Glue all rubber outdoor tiles at the seams
- Glue the rubber outdoor tiles or mats into the studs on the floor.
- When gluing to the ground, the max. space between each dot should not be more than 8cm
- Ensure that mats are dry before applying adhesive, and glue them to a dry and dust-free substrate.
- Apply adhesive in the direction of the gutter or along the slope.

DRAINAGE: (For outdoor tiles only)

All rubber tiles are permeable. Always ensure proper drainage underneath the rubber tiles when used outside. The tile being continuously under water should not affect the rubber's lifespan. The lifespan of the glue, however, could be shortened. When gluing the product, the drainage system should not be closed. Glue in the direction of the gutter or in the direction of the slope

MAINTENANCE INSTRUCTIONS:

- Remove loose dirt.
- Wipe the tiles with a damp cloth and a non-abrasive cleaning agent.
- Avoid using excessive water and refrain from using a scrubbing machine.
- Note: Only use non-abrasive cleaning agents.
- Always wear/use the appropriate protective gear when installing Aslon® products.
- For information about suitable cleaning agents, please contact Aslon Rubber.